

THIS EQUIPMENT IS ONLY TO BE USED BY FULLY CERTIFIED AND TRAINED PERSONAL. THE USER IS FULLY RESPONSIBLE FOR ANY INJURY OR DAMAGE RESULTING FROM THE USE OF THIS EQUIPMENT

Slip-on Pressure Tester Instructions:

Attach the SO-PT to the HPT-100 with a reducer bushing. Pull the main housing down & turn so the setscrew sits on the housing shoulder. Put the main housing just under the aerosol can valve curl press the can valve until it is fully attached to the housing. Now turn the main housing holding the HPT-100 with the other hand. Line up the setscrew with the slot in the main housing. The internal spring loaded stem will depress the stem of the actuator & register pressure.

For parts, service or questions please call

(870) 420-3613 or email us at info@aerotechlab.com

Aero-Tech Laboratory Equipment Company, LLC

6516A Terrapin Rd. Harrison, Arkansas 72601