

Slip-on Pressure Tester Instructions:

Attach the SO-PT to the HPT-100 with a reducer bushing. Pull the main housing down & turn so the set screw sits on the housing shoulder. Put the main housing just under the aerosol can valve curl press the can valve until it is fully attached to the housing. Now turn the main housing holding the HPT-100 with the other hand. Line up the set screw with the slot in the main housing. The internal spring loaded stem will depress the stem of the actuator & register pressure.

**For parts, service or questions please call
(417) 533-5552 or email us at info@aerotechlab.com**

**Aero-Tech Laboratory Equipment Company, LLC
21397 Tampa Drive, Lebanon, MO 65536
U.S.A.**