

Manual Can Crimper >>>>

The model 3000-C can crimper is designed for crimping all cans having a 1 inch opening. This unit is calibrated in our testing lab to give a crimp diameter of 1.070 and crimp height of .185. It has an adjustable plunger which permits the crimp diameter to be increased or decreased. Crimp height can be changed with additional nosepieces. All style and size cans can be crimped with this unit. The only maintenance required is a drop of oil on all moving parts periodically depending on use.

Price \$1,600.00

Collet #0140P-8 Split \$435.00 3000-C-P Plunger \$120.00

3000-C-SB Swing Bolt \$40.00 3000-C-NP \$200.00

<<<< Pneumatic Can Crimper

The model 4500-C pneumatic can crimper comes fully equipped with pneumatic controls and regulator and requires a 100 psi air supply. This crimper is virtually effortless to operate. With only a touch of a lever you can crimp 10-15 cans a minute. The unit is calibrated in our testing lab to give a crimp diameter of 1.070 and crimping height of .185. It has an adjustable plunger which permits the crimp diameter to be increased or decreased. Crimp height can be changed with additional nosepieces. Very operator friendly and requires no maintenance.

Price \$3,950.00

Collet #0140P-8 Split \$435.00 4500-C-P Plunger \$125.00

4500-C-NP Nosepiece \$195.00

Manual Bottle Crimper >>>>

The model 3000-B bottle crimper comes with a 20mm 12 split crimping collet. Other collets are available upon request. The collet is adjustable to increase or decrease crimp depth. It accepts any style or size bottle. The only maintenance required is a drop of oil on all moving parts periodically depending on use.

Price \$1,900.00

Collets, 12 split: 30869P-20mm, #0854OP-18mm, #0853-17mm, #0852P-15mm, & #2609R-13mm \$625.00

Collet, 32 split: #4475Q-20mm \$980.00 each. Available in other sizes, (Photo on front cover) Custom collets available upon request.

***When ordering please send 3 or 4 samples of bottles and valves so we can adjust the crimp depth. It will be ready for use when you receive it.**

<<<< Pneumatic Bottle Crimper

The model 4500-B pneumatic bottle crimper comes with a 20mm 12 split crimping collet. Other collets are available upon request. It comes fully equipped with pneumatic controls and regulator. The crimp depth is adjustable allowing you to increase or decrease it. There are almost no moving parts to wear out.

Price \$3,950.00

Collets 12 split: #0869P-20mm, #0854P-18mm, #0853P-17mm, #0852P-15mm, #2609R-13mm Price \$625.00

Collets 32 split: #4475Q-20mm \$980.00 each, available in all sizes. (Photo on front cover) Custom collets available upon request.

***Upon ordering, please send 3 or 4 samples of bottles and valves so we can adjust the crimp depth for you. It will be ready to use when you receive it.**

\$50.00 Crating charge for all crimpers

Prices are subject to change

