

Precision Test Gauge

For Testing, Inspection or Critical Production Processes

Hand and stationary pressure testers are protected by a stainless steel liquid filled diaphragm and calibrated on a dead weight tester. A serial number and a certification of accuracy are supplied (N.I.S.T. Traceable). They are also fitted with a instrument toggle valve for pre pressurizing. Adapters are optional at on additional cost



HPT-100

< HPT-100 Portable 3 inch Hand Pressure Tester

This gauge combines high accuracy with rugged construction accuracy + or - 0.5% of span. A cover is included.

Available in 100 psi, 160 psi, 200 psi and 300 psi. Other Ranges are available upon request.

Model HPT - 100 \$ 569.00

Electronic Digital > Pressure Gauge

HPT-100-E \$865.00

HVT-100-E \$865.00



HPT-100-E



HVT-100-E

Vacuum Tester Gauge

This gauge comes with a toggle instrument valve. A diaphragm seal is not necessary. Available in 30" HG. (Picture Not Shown)
Model HVT-100 \$ 625.00

Calibrations and Repairs are done on Premises! N.I.S.T. Test Reports issued With Calibrations.

For all Calibrations and Repairs, Send to Aero-Tech Laboratory Equipment Co.,LLC



Aerosol Can Tapping Valve ^

Allows the can to be permanently tapped and it's contents expulsion accurately controlled.

Adapters for Pressure & Vacuum Testers

Universal Male AP-UM Seaquist AR74 AP-AR74

Sequist AR83 AP-AR83 Newman Green AP-NG

Summit F83 AP-F83 Clayton AP-CL

Complete Set AP-CS

All Adapters are \$65.00 except the Clayton AP-CL \$95.00

A Complete set is \$300.00 *A complete set includes all adapters except The Clayton (Custom Adapters are Available)

Slip-On Pressure Tester Attachment >

This device is made of stainless steel and is spring loaded. It allows you to attach the pressure tester to the can for hands free Operation. Then the can may be submerged in a hot water bath for pressure testing.

SO-PT \$395.00



Pressure Test Unit >>>>

The design of this unit allows a can or vessel to be brought to the gauge with an extra sensitive touch, minimizing the chance of adapter damage. It gives you the third hand you need when prepressurizing. Pressure testing gauge can be installed or removed easily for portability.

PYU-500 \$800.00



Prices are subject to change